

## Using the Newton Print Pack

The Newton Print Pack allows you to connect your Newton device to a variety of printers that are configured to work with MS-DOS and Windows-based computers. These printers include ink jet, laser, dot-matrix, and thermal printers.

### Installing the Software on Your Newton Device

You need to install the software from the Macintosh or PC floppy disk on your Newton device before you can print from your Newton device on a parallel printer. To install the software, you need to use connectivity software, such as the Newton Connection Utilities, that came with your Newton device. For more information, see the documentation that came with your connectivity software.

**Note:** If you have a PC-Compatible computer, you need a 9- or 25-pin to DIN-8 serial cable.

## Connecting Your Newton Device to a Parallel Printer

You use the cable that came with the Newton Print Pack to connect your Newton device to a parallel printer. To determine which printer driver to use with your printer, see the section “Print Pack Compatibility List.” If your printer is not listed, you won’t be able to print from your Newton device to the printer.

- 1** Make sure you’ve installed the Newton Print Pack software on your Newton device.

See the earlier section, “Installing the Software on Your Newton Device.”

- 2** Turn off the printer.

- 3** Connect the parallel end of the cable to the appropriate port on your printer.

For more information, see the documentation that came with your printer.

- 4** Connect the other end of the cable to the serial port on your Newton device.

If you have a Newton Interconnect port, attach the Newton Serial Adapter to the serial end of the cable, then plug the adapter with the cable attached into the Newton Interconnect port on your Newton device.

- 5** Turn on the printer.

## Print Pack Compatibility List

This list specifies which printer driver to use for specific printers. If your printer is not listed, you won't be able to print from your Newton device to the printer.

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Acer	AcerLaser III G	LaserJet II
	LP-75	LaserJet II
	LP-76	LaserJet II
ACOM Computer, Inc.	LX-4808	LaserJet II
	LX-5824	LaserJet II
	MC-5812	LaserJet II
	MC-5815	LaserJet II
Advanced Matrix Technology	Accel-212	Epson FX
	Accel-213	Epson FX
	Accel-214	Epson FX
	Accel-241	Epson LQ
	Accel-242	Epson LQ
	Accel-242d	Epson LQ
	Accel-243	Epson LQ
	Accel-244	Epson LQ
	Accel-244 Persona Plotter	Epson LQ
	Accel-244d	Epson LQ
	Accel-292	Epson FX
	Accel-294	Epson FX
	Accel-342	Epson LQ
	Accel-342d	Epson LQ
	Accel-344	Epson LQ
	Accel-344d	Epson LQ
	Accel-500	Epson LQ
	Accel-525	Epson LQ
	Accel-535	Epson LQ

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
AEG Olympia AI/GBT	NPC 136-24	Epson LQ
	6824 XP	LaserJet II
	6840 XP	LaserJet II
	6845 XP	LaserJet II
ALPS	Allegro 24	Epson LQ
	Allegro 500	Epson LQ
	Allegro 500XT	Epson LQ
	ALQ 218	Epson FX
	ALQ 224	Epson LQ
	ALQ 224E	Epson LQ
	ALQ 224GX	Epson LQ
	ALQ 3001	Epson FX
	ALQ 318	Epson FX
	ALQ 324	Epson LQ
	ALQ 324E	Epson LQ
	ALQ 324GX	Epson LQ
	ASP 1000	Epson FX
	ASP 1600	Epson FX
	DMX 180	Epson LQ
	DMX 800	Epson FX
	LPX 2020	LaserJet II
	LSX 1000	LaserJet II
	LSX 1600	LaserJet II
	LSX 1600E	LaserJet II
	P2000+	Epson FX
	P2100	Epson FX
	P2400 C	Epson LQ
	P2418	Epson FX
P2424 C	Epson LQ	
Anzac Computer Equipment	2600	Epson FX
Apple Computer, Inc.	Portable Style Writer	Canon BJ-10ex

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
BottomLine Technologies	BT 5015	LaserJet II
	BT 5106	LaserJet II
Brother International Corporation	HJ-100i	Canon BJ-10ex
	HL-1060	LaserJet II
	HL-10H	LaserJet II
	HL-10V	LaserJet II
	HL-1260	LaserJet II
	HL-4	LaserJet II
	HL-4V	LaserJet II
	HL-4Ve	LaserJet II
	HL-6	LaserJet II
	HL-630	LaserJet II
	HL-630M	LaserJet II
	HL-631	LaserJet II
	HL-641	LaserJet II
	HL-645	LaserJet II
	HL-645M	LaserJet II
	HL-650	LaserJet II
	HL-655M	LaserJet II
	HL-660	LaserJet II
	HL-6V	LaserJet II
	HL-730	LaserJet II
	HL-730DX	LaserJet II
	HL-760	LaserJet II
	HL-8e	LaserJet II
	HL-8V	LaserJet II
	HL-960	LaserJet II
	M-1109	Epson FX
	M-1209	Epson FX
M-1309	Epson FX	
M-1324	Epson LQ	

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Bull	CompuPrint 4/54	Epson LQ
	CompuPrint 4/66	Epson FX
	CompuPrint 4/68	Epson FX
	CompuPrint 922N Plus	Epson FX
	CompuPrint 923 Plus	Epson FX
	CompuPrint 924 Plus	Epson LQ
	CompuPrint 924N Plus	Epson LQ
	CompuPrint 956	Epson LQ
	CompuPrint 970	Epson FX
	LP-230	LaserJet II
	PageMaster 1021	LaserJet II
	PageMaster 1025	LaserJet II
	PageMaster 1725	LaserJet II
	PageMaster 201	DeskJet
	C. Itoh/C-Tech Electronics, Inc.	9500
9515		Epson FX
9715		Epson LQ
C-240		Epson FX
C-245		Epson FX
C-310		Epson FX
C-315		Epson FX
C-410		Epson FX
C-415		Epson FX
C-420		Epson FX
C-425		Epson LQ
C-510		Epson LQ
C-515		Epson LQ
C-610		Epson LQ
C-610 +		Epson LQ
C-610C +		Epson LQ
C-610II		Epson LQ
C-610III		Epson LQ

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
	BJC-250	Canon BJC
	BJC-4000	Canon BJC
	BJC-4100	Canon BJC
	BJC-4200	Canon BJC
	BJC-4300	Canon BJC
	BJC-4300	Canon BJC
	BJC-4550	Canon BJC
	BJC-5500	Canon BJC
	BJC-600	Canon BJC
	BJC-600e	Canon BJC
	BJC-610	Canon BJC
	BJC-620	Canon BJC
	BJC-70	Canon BJC
	BJC-80	Canon BJC
	BJC-820	Epson LQ
	CFX-B380IF	Canon BJC
	LBP-1260	LaserJet II
	LBP-4 sx	LaserJet II
	LBP-430	LaserJet II
	LBP-8 sx	LaserJet II
	MultiPASS 1000	Canon BJ-10ex
	Multipass C2500	Canon BJC
	Multipass C3000	Canon BJC
Casio	LCS 240	Epson FX
	LCS 300	Epson FX
CIE	CI-250 GXP	Epson FX
	CI-250 LXP	Epson FX
	CI-4000	Epson FX
	CI-5000	Epson FX
	CI-5000CX	Epson FX
	CI-5000TX	Epson FX
Citizen Corporation	120D	Epson FX
	120D+	Epson FX

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Citizen Corporation	Swift 9	Epson FX
	Swift 9X	Epson FX
Commodore	MPS-1000	Epson FX
Compaq	PageMarq 15	LaserJet II
	PageMarq 20	LaserJet II
Continental Systems	L-2060	LaserJet II
Copal	SC-1250	Epson FX
	SC-5930	Epson FX
	SC-6730	Epson LQ
	Writehand 5900	Epson FX
	Writehand 5930	Epson FX
	Writehand 6700	Epson LQ
	Writehand 6730	Epson LQ
	CSS Laboratories	OAW153
OAW223		LaserJet II
CTSI International	Infoscribe 1000	Epson FX
	Infoscribe 1100	Epson FX
Daisy Systems	M7001	Epson FX
	M8001	Epson LQ
Data General Corporation	6514	Epson LQ
	6515	Epson LQ
	6594	Epson FX
	6617	Epson FX
	6618	Epson FX
	6640	LaserJet II
	6640T	LaserJet II
	6771	LaserJet II
	6772	LaserJet II
	6773	LaserJet II
6789	Epson FX	
Dataco Derex, Inc.	S 3000II	LaserJet II
Dataproducts Corporation	6298	Epson FX
	8500	Epson FX



<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Digital Equipment Corp.	6415	Epson FX
	ColorWriter 120ic	DeskJet
	ColorWriter 550IC	DeskJet
	DecJet 1000	DeskJet
	DecJet 2000	DeskJet
	DecLaser 1800	LaserJet II
	DecLaser 3200	LaserJet II
	DecLaser 3250	LaserJet II
	DecWriter 100i	DeskJet
	DecWriter 500i	Epson LQ
	DecWriter 55	Epson LQ
	DecWriter 65	Epson LQ
	DecWriter 90i	DeskJet
	DecWriter 95	Epson LQ
	LA600 MultiPrinter	Epson LQ
	LG04 Plus	Epson FX
	Eastman Kodak Company	Diconix 180si
Diconix 300		Epson FX
Diconix 300W		Epson FX
Diconix 701		DeskJet
Electronic Form	Formwriter 10	LaserJet II
	Formwriter 10X	LaserJet II
	Formwriter 10XD	LaserJet II
	Formwriter 2	LaserJet II
	Formwriter 2E	LaserJet II
	Formwriter 2EX	LaserJet II
	Formwriter 2EXD/MX	LaserJet II
	Formwriter 2X	LaserJet II
	Formwriter 4	LaserJet II
Formwriter 8	LaserJet II	
Epson America, Inc.	ActionLaser	LaserJet II
	ActionLaser 1000	LaserJet II
	ActionLaser 1100	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Epson America, Inc.	FX-100 +	Epson FX
	FX-1050	Epson FX
	FX-1170	Epson FX
	FX-185	Epson FX
	FX-2070	Epson Stylus
	FX-2170	Epson FX
	FX-286	Epson FX
	FX-286e	Epson FX
	FX-80	Epson FX
	FX-80 +	Epson FX
	FX-85	Epson FX
	FX-850	Epson FX
	FX-86e	Epson FX
	FX-870	Epson FX
	HS-80	Epson FX
	JX-80	Epson FX
	L-1000	Epson LQ
	L-750	Epson LQ
	LQ 2070	Epson LQ
	LQ-1000	Epson LQ
	LQ-1010	Epson LQ
	LQ-1050	Epson LQ
	LQ-1060	Epson LQ
	LQ-1070	Epson LQ
	LQ-1070+	Epson Stylus
	LQ-1170	Epson Stylus
	LQ-1500	Epson LQ
	LQ-200	Epson LQ
	LQ-2170	Epson Stylus
	LQ-2500	Epson LQ
	LQ-2550	Epson LQ
	LQ-300	Epson LQ
	LQ-500	Epson LQ

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Epson America, Inc.	T-750	Epson FX
Esselte Meto	LIS-1120	LaserJet II
	LIS-1520	LaserJet II
	LIS-1520a	LaserJet II
Facit	B1200	Epson FX
	B2100	Epson FX
	B2150	Epson FX
	B2400	Epson LQ
	B2450	Epson LQ
	B3100	Epson FX
	B3150	Epson FX
	B3150C	Epson FX
	B3350C	Epson FX
	B3450C	Epson LQ
	B3550C	Epson FX
	C7400	Epson FX
	C7500	Epson FX
	D2600	Epson LQ
	D4000	Epson FX
	E420	Epson FX
	E520	Epson FX
	E530	Epson FX
	E580	Epson LQ
	E590	Epson LQ
	E620	Epson FX
	E630	Epson FX
	E670	Epson LQ
	E690	Epson LQ
	E750	Epson FX
	E7650	Epson FX
	E950	Epson FX
	P5160	LaserJet II
	P6060	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Fujitsu America, Inc.	DL 4600	Epson LQ
	DL 4600C	Epson LQ
	DL 5600	Epson FX
	DL 5600C	Epson FX
	DL 5800	Epson LQ
	DL 5800C	Epson LQ
	DL 6400	Epson Stylus
	DL 700	Epson Stylus
	DX 2300	Epson FX
	DX 2400	Epson FX
	Print Partner 10	LaserJet II
	Print Partner 10I	LaserJet II
	Print Partner 4000	LaserJet II
	Print Partner 8000	LaserJet II
	VM 2200	LaserJet II
	General Business	GBT 6624 XP
GBT 6824 XP		LaserJet II
GBT 6840 XP		LaserJet II
Genicom Corporation	1020	Epson FX
	1025	Epson FX
	1030	Epson LQ
	1040	Epson LQ
	1220	Epson LQ
	220	Epson FX
	240	Epson FX
	3810S	Epson FX
	3820	Epson FX
	3840	Epson FX
	3840 E	Epson FX
	3840 EM	Epson FX
	4810	Epson FX
	4840	Epson FX
	6100	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Hewlett Packard Company	DeskJet 1200C/PS	DeskJet
	DeskJet 1600C	DeskJet
	DeskJet 1600CM	DeskJet
	DeskJet 1600CN	DeskJet
	DeskJet 310	DeskJet
	DeskJet 320	DeskJet
	DeskJet 340	DeskJet
	DeskJet 400	DeskJet
	DeskJet 500	DeskJet
	DeskJet 500C	DeskJet
	DeskJet 520	DeskJet
	DeskJet 540	DeskJet
	DeskJet 550C	DeskJet
	DeskJet 560C	DeskJet
	DeskJet 600	DeskJet
	DeskJet 600C	DeskJet
	DeskJet 660C	DeskJet
	Deskjet 670C	DeskJet
	DeskJet 672C	DeskJet
	DeskJet 680C	DeskJet
	DeskJet 682C	DeskJet
	DeskJet 690C	DeskJet
	Deskjet 692C	DeskJet
	DeskJet 693C	DeskJet
	DeskJet 694C	DeskJet
	DeskJet 870csi	DeskJet
	Deskjet 890C	DeskJet
	Deskjet 890Cxi	DeskJet
	DeskJet Plus	DeskJet
	DeskJet Portable	DeskJet
	LaserJet 4	LaserJet II
	LaserJet 4+	LaserJet II
	LaserJet 4000	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>	
Hewlett Packard Company	OfficeJet 500	DeskJet	
	OfficeJet 570	DeskJet	
	OfficeJet 600	DeskJet	
	OfficeJet 610	DeskJet	
	OfficeJet 630	DeskJet	
	OfficeJet LX	DeskJet	
	Officejet Pro 1150C	DeskJet	
	PaintJet XL300	LaserJet II	
	RuggedWriter	Epson LQ	
	RuggedWriter 480	Epson LQ	
	Scanjet 5P	DeskJet	
	Hyundai	HDP-1810	Epson FX
		HDP-1820	Epson FX
HDP-910		Epson FX	
HDP-920		Epson FX	
HLP-6000		LaserJet II	
Pinovia 2430		Epson LQ	
Pinovia 2440		Epson LQ	
IBM/Lexmark	3912-AS0	LaserJet II	
	3912-AS1	LaserJet II	
	3912-NS0	LaserJet II	
	3916 PagePrinter AS0	LaserJet II	
	3916 PagePrinter AS1	LaserJet II	
	3916 PagePrinter NS0	LaserJet II	
	3916 PagePrinter NS1	LaserJet II	
	3930 PagePrinter 03D	LaserJet II	
	3930 PagePrinter 03S	LaserJet II	
	4019 LaserPrinter	LaserJet II	
	4019 LaserPrinter E	LaserJet II	
	4029-10 LaserPrinter 5E	LaserJet II	
	4029-20 LaserPrinter 6	LaserJet II	
	4029-22 LaserPrinter 6P	LaserJet II	
	4029-30 LaserPrinter 10	LaserJet II	

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
IBM/Lexmark	Optra R+	LaserJet II
	Optra Rn +	LaserJet II
	Optra Rt +	LaserJet II
	Optra Rx	LaserJet II
	WinWriter 600	LaserJet II
Idea Courier	13087	Epson FX
	13412-06	LaserJet II
	13X34	Epson FX
	13X54	Epson FX
	13X80	Epson FX
Ideal	850 DL	LaserJet II
	850 XL	LaserJet II
	Demon 480	LaserJet II
Impression Technology	500 Twin-Ax	Epson LQ
	ZL1 Coax	LaserJet II
	ZL1 Twin-Ax	LaserJet II
Interface Systems, Inc.	9624	LaserJet II
	ISI-7028	LaserJet II
	ISI-7028	LaserJet II
	ISI-7028D	LaserJet II
	ISI-7812	LaserJet II
JDL	AutoPlotter	Epson LQ
	AutoPlotter XP	Epson LQ
	OmniPlotter	Epson LQ
JPS MicroSystems	MAXX/8	LaserJet II
JRL Systems, Inc.	JR670-1	Epson LQ
Kentek Information Sys., Inc.	K-2 +	LaserJet II
	K-3	LaserJet II
	K-30	LaserJet II
	K-30D	LaserJet II
	K-4	LaserJet II
	K-40D	LaserJet II
	K-60	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Kyocera Electronics, Inc.	FS-400	LaserJet II
	FS-400A	LaserJet II
	FS-6500	LaserJet II
	IPH	LaserJet II
	IPH-3500	LaserJet II
	IPH-3503	LaserJet II
	IPH-3503C	LaserJet II
	IPH-3504	LaserJet II
Lanier	1160 MFD	LaserJet II
Lasermaster Corporation	Unity Turbo XL	LaserJet II
Lee Data	1314	Epson FX
	1314W	Epson FX
	1315	Epson FX
Lexi Corporation	1012	LaserJet II
	1019 II	LaserJet II
	2012	LaserJet II
Mannesmann Tally Corp.	MT 130/9	Epson FX
	MT 130/24	Epson LQ
	MT 131/9	Epson FX
	MT 131/24	Epson LQ
	MT 150/24	Epson LQ
	MT 150/9	Epson FX
	MT 151/24	Epson LQ
	MT 151/9	Epson FX
	MT 222	Epson LQ
	MT 230/9	Epson FX
	MT 230/24	Epson LQ
	MT 290	Epson FX
	MT 330	Epson LQ
	MT 340	Epson FX
	MT 350	Epson LQ
	MT 360	Epson LQ
	MT 490	Epson FX



<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Mita Copystar	LP-2085	LaserJet II
	LP-3155	LaserJet II
	LP-3160	LaserJet II
NCR	577	Epson FX
	6417	Epson FX
	6421	Epson FX
	6424	Epson FX
	6435	LaserJet II
	6436-0301	LaserJet II
	6436-0501	LaserJet II
NEC Technologies, Inc.	Intellitech	LaserJet II
	Intellibar 412	
NEC Technologies, Inc.	JetMate	DeskJet
	Silentwriter LC 260	LaserJet II
	Silentwriter LC 860	LaserJet II
	SuperScript 100C	LaserJet II
	SuperScript 860	LaserJet II
Newbury Data	OSP 3	Epson FX
Nissho	NP 2405	Epson LQ
	NP 2410	Epson LQ
Octus	LaserPro 90/22 Plus	LaserJet II
	LaserPro 90/24E	LaserJet II
Office Automation	LaserPro 90/22	LaserJet II
	LaserPro 90/8	LaserJet II
	LaserPro Exec	LaserJet II
Okidata	DOC*IT 4000	LaserJet II
	LaserLine 6	LaserJet II
	Microline 280	Epson FX
	MicroLine 320	Epson FX
	MicroLine 320 Elite	Epson FX
	MicroLine 320 Turbo	Epson LQ
	MicroLine 321	Epson FX
	MicroLine 321 Elite	Epson FX

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>	
Okidata	OkiLaser 810	LaserJet II	
	OkiLaser 810e	LaserJet II	
	OkiLaser 810e/PS	LaserJet II	
	OkiLaser 820	LaserJet II	
	OkiLaser 830	LaserJet II	
Okidata	OkiMate 240	Epson LQ	
Okidata	Okipage 16n	LaserJet II	
	OkiPage 4w	LaserJet II	
	Okipage 6e	LaserJet II	
	Okipage 6ex	LaserJet II	
	PaceMark 3410	Epson FX	
	Olivetti	DM 100S	Epson FX
		DM 105S	Epson FX
DM 124		Epson LQ	
DM 309E		Epson FX	
DM 600S		Epson LQ	
DOC*IT 3000		LaserJet II	
JP 150		DeskJet	
JP 350		DeskJet	
JP 450		DeskJet	
PG 306		LaserJet II	
Olympus Image Sys. Inc.	Deltis PagePlex 18	LaserJet II	
	MegaServe/45	LaserJet II	
OTC	2132	Epson FX	
	2142	Epson FX	
	2162	Epson FX	
	4130	Epson FX	
	4140	Epson FX	
	560 DL	Epson FX	
	850 Printnet	Epson FX	
	850 XL	Epson FX	
	888 XL	Epson FX	
888 XL/Model 2	Epson FX		

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Panasonic Communications & Systems	KX-P1090	Epson FX
	KX-P1091	Epson FX
	KX-P1091i	Epson FX
	KX-P1092	Epson FX
	KX-P1092i	Epson FX
	KX-P1093	Epson FX
	KX-P1123	Epson LQ
	KX-P1124	Epson LQ
	KX-P1124i	Epson LQ
	KX-P1150	Epson FX
	KX-P1160	Epson FX
	KX-P1180	Epson FX
	KX-P1180i	Epson FX
	KX-P1191	Epson FX
	KX-P1524	Epson LQ
	KX-P1592	Epson FX
	KX-P1595	Epson FX
	KX-P1624	Epson LQ
	KX-P1654	Epson LQ
	KX-P1695	Epson FX
	KX-P2023	Epson LQ
	KX-P2123	Epson LQ
	KX-P2124	Epson LQ
	KX-P2130	Epson LQ
	KX-P2135	Epson LQ
	KX-P2180	Epson FX
	KX-P1091	Epson FX
	KX-P1091i	Epson FX
	KX-P1092	Epson FX
	KX-P1092i	Epson FX
	KX-P1093	Epson FX
	KX-P1123	Epson LQ

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Panasonic Communications & Systems	KX-P6500	LaserJet II
	KX-SP100	LaserJet II
	Sigma-100	LaserJet II
PCPI	1030	LaserJet II
	1030-ID	LaserJet II
	1030-IS	LaserJet II
	1030-LN03+	LaserJet II
	1030-PP	LaserJet II
	1032	LaserJet II
	1034	LaserJet II
	1035	LaserJet II
	1100-PS	LaserJet II
	2020	LaserJet II
	2020-ID	LaserJet II
	2020-IS	LaserJet II
	2024	LaserJet II
	2025	LaserJet II
	2500-ID	LaserJet II
	2500-IS	LaserJet II
	2500-OA	LaserJet II
	2500-PP	LaserJet II
	3020	LaserJet II
	3020-ID	LaserJet II
	3020-IS	LaserJet II
	3020-LN03+	LaserJet II
	3020-PP	LaserJet II
	3022	LaserJet II
	3024	LaserJet II
	3025	LaserJet II
Pentax Technologies	Laserfold 240	Epson FX
	PocketJet	LaserJet II
Prime Computer	3451	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Roland	PR-1515	Epson LQ
	PR-2416	Epson LQ
	PR-2417	Epson LQ
	PR-2418	Epson LQ
	PR-2465	Epson LQ
	PR-9101	Epson FX
	PR-9104	Epson FX
	PR-9606	Epson FX
Rosetta Technologies Corp.	RT3216	LaserJet II
	Continuous Laser	
	RT3316M	LaserJet II
	Contin. MICR Laser	
	RT4115	LaserJet II
	RT4224	LaserJet II
	RT4224M MICR	LaserJet II
	RT4230	LaserJet II
	RT4324 Duplex	LaserJet II
	RT4330 Duplex	LaserJet II
RT4430	LaserJet II	
RT4530 Duplex	LaserJet II	
Royal Consumer Business Products	CJP 450	DeskJet
Samsung	Finale 8000	LaserJet II
	ML-85	LaserJet II
	QwikLaser QL85	LaserJet II
	SP-0912	Epson FX
	SP-0930N	Epson FX
	SP-2412	Epson FX
	SP-2417	Epson LQ
	SP-2420	Epson LQ
SP-2431	Epson LQ	
Sanyo	MFP-510	LaserJet II
	PR-241	Epson LQ

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Seikosha	SL-270	Epson LQ
	SL-532	Epson LQ
	SL-70	Epson LQ
	SL-80 AI	Epson LQ
	SL-90	Epson LQ
	SL-90 AI	Epson LQ
	SL-90 Plus	Epson LQ
	SL-92 Plus	Epson LQ
	SP-10 Plus	Epson FX
	SP-1600 AI	Epson FX
	SP-185 AI	Epson FX
	SP-1900 Plus	Epson FX
	SP-2000 AI	Epson FX
	SP-2000 Plus	Epson FX
	SP-2000 S	Epson FX
	SP-2400	Epson FX
	SP-2415	Epson FX
	SP-2450	Epson FX
	Sharp Electronics Corp.	JX-9460PS
JX-9500		LaserJet II
JX-9500H		LaserJet II
JX-9500PS		LaserJet II
JX-9550		LaserJet II
JX-9600		LaserJet II
Siemens Nixdorf Printing Systems LP	JX-9700	LaserJet II
	HighPrint 730	DeskJet
	HighPrint 735	DeskJet
	LP 2030-1	LaserJet II
	LP PT 88 S	Epson FX
	LP PT 89 S	Epson FX
Star Micronics America, Inc.	LaserPrinter 4	LaserJet II
	LaserPrinter 8III	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Star Micronics America, Inc.	XB 2420	Epson LQ
	XB 2425	Epson LQ
	XR 1000	Epson FX
	XR 1020	Epson FX
	XR 1500	Epson FX
	XR 1520	Epson FX
Storage Technology	6024T	LaserJet II
Sun	Sparcprinter EC	LaserJet II
Swintec	SP 3624 DX	Epson FX
	SP 824 DX	Epson FX
Synergystex	CF1000	LaserJet II
Talaris Systems Inc.	1590	LaserJet II
	1794 Printstation	LaserJet II
	1794FT Imagestation	LaserJet II
	2090	LaserJet II
	2090 Printstation	LaserJet II
	2090-FT	LaserJet II
	2090-FT Imagestation	LaserJet II
	2090-S	LaserJet II
	3290-FT	LaserJet II
	Tandem Computers Inc.	5573D Laser
Tandy/Radio Shack	DMP 103	Epson FX
	DMP 135	Epson FX
	DMP 136	Epson FX
	DMP 137	Epson FX
	DMP 2103	Epson LQ
	DMP 2104	Epson LQ
	DMP 2130	Epson FX
	DMP 240	Epson LQ
	DMP 302	Epson LQ
	LP 1000	LaserJet II
	LP 950	LaserJet II
	LP 990	LaserJet II

<b>MANUFACTURER</b>	<b>PRINTER MODEL</b>	<b>PRINTER DRIVER</b>
Toshiba	Expresswriter 201	Epson LQ
	Expresswriter 420	Epson LQ
	Expresswriter 440	Epson LQ
	GX200	LaserJet II
	GX400	LaserJet II
	Linear MFD 5010	LaserJet II
	PageLaser 12	LaserJet II
	PageLaser 6	LaserJet II
Troy	410	LaserJet II
	508 MICR	LaserJet II
Unisys	AP 1324	Epson LQ
	AP 1327	Epson FX
	AP 1329	Epson FX
	AP 1337	Epson LQ
	AP 1339	Epson LQ
	AP 1357	Epson LQ
	AP 1359	Epson LQ
	AP 1371	Epson FX
	AP 9205	LaserJet II
	AP 9210	LaserJet II
	AP 9310	LaserJet II
	AP 9312	LaserJet II
Wang	DM50/300	Epson FX
	DM66/200	Epson LQ
	HQ300	Epson LQ
	LDP-8	LaserJet II
	PM060	Epson LQ
Xerox Corp.	3006	DeskJet
	4011	LaserJet II
	4030 II	LaserJet II
	4045 Model 160	LaserJet II
	4197 MICR	LaserJet II
	4213	LaserJet II